

جامعة بيرزيت
BIRZEIT UNIVERSITY

Reinforced Concrete Design I
ENCE 335

Analysis and design of T-beams

Dr. Khalil M. Qatu

What are T-section beams

- In most cases, Slabs and beams are cast at the same time
- Forms are built for the beams' sides and bottoms as well as the bottom of the slab
- This is called Monolithic construction
- In This case, part of the slab (its transverse direction) will resist comp. forces with the upper part of the beam.
- This part of the slab forms the Flanges of the beam and the drop part of the beam is Stem or Web.
- The resulting cross-section is T-Shaped







What are T-section beams

- Effective width
  - For non-prestressed T-beams supporting monolithic or composite slabs.
  - The effective flange width b_f shall include the beam web width b_w plus an effective overhanging flange width in accordance with Table 6.3.2.1
  - Where h is the slab thickness and s_w is the clear distance to the adjacent web.

Table 6.3.2.1—Dimensional limits for effective overhanging flange width for T-beams

Flange location	Effective overhanging flange width, beyond face of web	
Each side of web	Least of:	$8h$
		$s_w/2$
		$l_n/8$
One side of web	Least of:	$6h$
		$s_w/2$
		$l_n/12$





What are T-section beams

- In some cases, engineers choose a T-shaped cross-section to increase the available compression area in the beam.

- The ACI code requires :
  - Flange thickness $\geq 0.5b_w$
  - Effective flange width $\leq 4b_w$





Analysis of T-sections

- The N.A. of the beam may lie either in the FLANGE or in the WEB.
- This depends on the section geometry, material properties, and the amount of tensile steel.
- If $N.A. \leq h_f$: the beam can be analyzed as a rectangular section with width B_f and depth H.
  - WHY?

- If $N.A. \geq h_f$: the compression area is divided into two parts
  - The first part is the flange over-hang from each side which is coupled with part of the tension steel (A_{sf})
  - The second Part is the portion of the Web in compression which is coupled with the rest of the tension steel ($A_s - A_{sf}$)
- What is the Direction of the moment?? (+ or -)





Analysis of T-sections







Analysis of T-sections

- Tension Reinforcement limits
  - Minimum reinforcement remains the same ($\rho_w > \rho_{min}$)
  - Maximum reinforcement allowed by ACI code still maintains a tension strain in steel $\epsilon_t \geq 0.004$
    - We can calculate and compare the strain in the tension steel with the limit from the strain distribution

$$\epsilon_s = \epsilon_u \frac{d - \bar{y}}{\bar{y}} \geq 0.004$$



  - Or we can use this formula (derived from strain distribution and section equilibrium)

$$\bar{\rho}_{0.004} = \rho_{0.004} + \rho_f$$

Analysis of T-sections

Example: Calculate the Moment capacity of the given cross-section

$f_y = 420\ MPa$ …… $f_c' = 21\ MPa$



Analysis of T-sections

Example: Design

The floor system shown, consists of a 75mm concrete slab supported by continuous beams with 7.5 m span, and 1.2m center to center spacing. The Web dimensions were determined using the negative moment. Design the interior beam B1 indicated below knowing that the ultimate positive moment ($M_u = 750\ kN.m$)

$$f_y = 420\ MPa \ \ldots\ldots f_c' = 21\ MPa$$

$$b_e = min\left\{\begin{array}{c} 2(8h) + b_w = 1475\ mm \\ 2\left(\frac{s_w - b_w}{2}\right) + b_w = 1200\ mm \leftarrow \\ 2\left(\frac{l_n}{8}\right) + b_w = 2150\ mm \end{array}\right\}$$

Table 6.3.2.1—Dimensional limits for effective overhanging flange width for T-beams

Flange location	Effective overhanging flange width, beyond face of web	
Each side of web	Least of:	$8h$
		$s_w/2$
		$l_n/8$
One side of web	Least of:	$6h$
		$s_w/2$
		$l_n/12$





Arbitrary cross-sections