



To
ENEE236
Analog Electronics

Instructor
Mr. Nasser Ismail (Office
Masri220)
nismail@birzeit.edu

**Main Reference1 (~ text book) : Electronic Devices and Circuit Theory
, 10th Edition by R. Boylestad & L. Nashelsky**

Main Reference 2: Electronic Devices, 8th edition, by Floyd

1

Course Objectives

- Study diode construction, basic operating principles and modeling.
- To analyze and design diode based circuits used in different applications such as ac-dc rectifiers, limiting and clamping, voltage multiplication.
- To Study zener diode operation and usage as voltage regulator.
- To Study construction, operation, biasing of Bipolar Junction Transistors and Field Effect Transistors.
- To design and analyze BJT and FET based amplifier circuits using small signal analysis techniques including their high and low frequency response
- To study operational amplifiers and how to use them in various applications such as amplification, summation, comparison, integration, differentiation
- To study different discrete and integrated circuit Voltage Regulators and be able to design them for different applications

2

Course Contents

1. Introduction to Semiconductors and Semiconductor diodes
 - Atomic Structure; Semiconductors , Conductors And Insulators; Covalent Bonds;
 - Conduction in Semiconductors; N-Type and P-Type Semiconductors
 - The diode; biasing a Diode; V-I Characteristics of a Diode; Diode Models
2. Diode Applications
 - Load Line Analysis, Half-Wave and Full-Wave Rectifiers; Power supply Filters and Regulators; Diode Limiting and Clamping Circuits; Voltage Multipliers; The diode Data Sheet, Zener Diodes and their Applications
3. Bipolar Junction Transistors (BJT)
 - Transistor construction and operation, Transistor Characteristics and Parameters; The Transistor as an Amplifier; The Transistor as a Switch.
4. DC Biasing of BJTs
The DC Operating Point (Quiescent Operating Point); Voltage-Divider Bias; Other Bias Methods.

3

Course Contents

5. BJT AC Analysis
Amplifiers and small signal analysis, Transistor AC Equivalent Circuits- Hybrid Parameters, Common-Emitter Amplifier; Common-Collector Amplifier; Common-Base Amplifier; Multistage Amplifiers.
6. Field-Effect Transistors (FETs)
The JFET; JFET Characteristics and Parameters; JFET Biasing; The MOSFET Characteristics and Parameters; MOSFET Biasing
7. FET Amplifiers.
FET Amplification; Common-Source Amplifiers; Common- Drain Amplifiers and Common-Gate Amplifiers;
8. Operational Amplifiers and Applications
Introduction to Operational Amplifiers; Op-Amp Input Modes and Parameters Negative Feedback; Op-Amps with Negative Feedback ; Comparators; Summing Amplifiers; Integrators and Differentiators.
Instrumentation Amplifier; Converters and Other Op-Amp Circuits.

4

Course Contents

9. Amplifier Frequency Response

Basic Concepts; The Decibel; Low-Frequency Amplifier Response.

High-Frequency Amplifier Response; Total Amplifier Frequency Response.

10. Voltage Regulators

Voltage Regulation; Basic Series Regulator; Basic shunt Regulator; Integrated Circuit Voltage Regulators.

Grading Policy

Quizzes	15 %
Pspice assignments and Quizzes	10%
Midterm	30%
Final Exam:	45%

*

Introduction to Semiconductors and Semiconductor Diodes

7

Electronics Circuits

- We encounter electronics in our daily life in form of telephones, radios, television, audio equipment, home appliances, computer and equipment for industrial control and automation .




- ▶ The field of electronics deals with the design and application of electronic design .

Electronics Devices


► Diodes

- a) Rectifier diode
- b) Zener diode
- c) **L**ight **E**mitting **D**iode (**LED**)



► Transistors

- a) **B**ipolar **J**unction **T**ransistor (**BJT**)
- b) **F**ield **E**ffect **T**ransistor (**FET**)





► Integrated Circuits (IC)




Diode


- It is an electronic device with a single **p-n** junction and it has the ability to conduct current in one direction while blocking current in the other direction.

► Circuit Symbol :



- Physical construction







Semiconductors

- ▶ Electronic devices as diodes, transistors and integrated circuits are made of semiconductor material .
- Semiconductors : materials whose resistance lies between **low** resistance of **conductor** and the high resistance of **insulator** .

Atomic Structure




Covalent band



Covalent bond


- ▶ A silicon (Si) atom with its four valence electrons shares an electron with each of its four neighbors
- ▶ This effectively creates eight shared valence electrons for each atom and produces a state of chemical stability .

- Also, this sharing of valence electrons produce the covalent bonds that hold the atom together; each valence electron is attracted equally by the two adjacent atoms which share it .




Covalent bond in silicon crystals

- At absolute zero degree all valence electrons are tightly bonded to their atoms and there is no free electrons, so the silicon behave as an insulator .



Rupture of the a covalent bond


- ▶ When an electron becomes free that is unattached to any atom, a vacancy is left in the valence band within the crystal . This vacancy is called **hole** .
- ▶ For every free **electron**, there is one **hole** .
- ▶ One broken covalent bond → one free **electron** + one **hole**
- ▶ At room temperature there is one broken covalent bond for every 3×10^{12} pure Si atoms .





- At room temperature there are few available charge carriers (free **electrons** + **holes**)

Hole motion

- When a valence **electron** moves left to right to fill a **hole** while leaving another **hole** behind, the hole has effectively moved from right to left.





ENEE236 – Analog Electronics

Free electrons & Holes

The diagram shows a 3x3 grid of blue circles representing atoms. Each atom is connected to its four neighbors by pairs of curved lines representing covalent bonds. In the center atom, the top-right bond is broken, indicated by a dashed line. An arrow labeled "Broken bond" points to this dashed line. Another arrow labeled "Free electron" points to a single electron (represented by a small dash) that has been released from the broken bond. Below the diagram, text explains that thermal energy can break a bond, creating a vacancy and a free electron, both of which can move freely through the crystal.

Thermal energy can break a bond, creating a vacancy and a free electron, both of which can move freely through the crystal.

ENEE236 – Analog Electronics

Holes movement

The diagram shows a 4x6 grid of blue circles with minus signs, representing electrons in covalent bonds. In the top row, the first circle is empty, labeled "Empty state (hole)". An arrow points from the second circle to the first, indicating the hole's movement. In the top row, the fifth and sixth circles are labeled "Electrons in covalent bonds". Arrows show electrons moving from the fifth and sixth circles to the fourth circle. A vertical arrow on the left labeled "Time increasing" points downwards. In the second row, the hole has moved to the second position, and an arrow shows an electron from the third position moving to the second. This process repeats in the third and fourth rows, showing the hole moving to the third and then the fourth position as electrons move to fill it from the right.

As electrons move to the left to fill a hole, the hole moves to the right.


Doping

- A manufacturing process that adds free charge carriers (free **electron** or **hole**) into a pure semiconductor material to increase its conductivity
- There is two categories of impurities: n-type or p-type

- **N-Type Semiconductor**

- Pentavalent impurity (one which has 5 valence electrons) atom is added such as phosphorus
- This atom forms covalent bonds with 4 adjacent silicon atoms, while the fifth becomes a conduction electron since it is not attached to any atom

n-type silicon



With the number of electrons increasing, the rate of recombination between free electrons and holes also increase

n-type silicon is created by adding valence five impurity atoms.

ENEE236 – Analog Electronics


- Number of conduction electrons can be carefully controlled by the number of impurities added
- Since most of the current carriers are electrons, this type of material doped with pentavalent impurities is an n-type semiconductor
- The majority current carriers in n-type material is electrons, but there are few holes created when electron-hole pair are thermally generated, these holes are minority carriers

ENEE236 – Analog Electronics

P-Type Semiconductor

- To increase number of holes in intrinsic silicon, trivalent impurity atoms are added (atoms with three valence electrons) such as boron (B) or gallium (Ga)
- Valence electrons (3) of the impurity atom create covalent bonds with three adjacent atoms of silicon and a fourth electron is missing, creating a hole with each added impurity atom
- Majority carriers in P-type material are holes
- Also there are few free electrons that are created when electron-hole pair are thermally generated, these electrons are minority carriers


p-type silicon



p-type silicon is created by adding valence three impurity atoms.


Pn junction

► The p-n junction is the basis for diodes, certain transistors, and other devices.



Formation of Depletion Region

- 1) **Electrons** from the **n-type** material near the junction diffuse across the junction.
- 2) These **electrons** fill the **holes** in the **p-type** material adjacent to the junction.
- 3) As a result of **electrons** leaving the **n-type** material, donor ions are created on the n side of the junction.
- 4) When these **electrons** fill holes in the **p side** of the junction, acceptor ions are produced.
- 5) A wall of stationary **positive** ions is aligned with a wall of **negative** ions along the **n** and **p** sides of the junction.




- 6) The space occupied between the ion walls is called **depletion region**.

7) Whenever there exists a **positive** charge with respect to a **negative** charge, a voltage difference is set between charges; (**Junction potential**, **Junction barrier**).


8) The **junction potential** acts as **potential barrier** that tend to prevent majority carriers from crossing the junction.

9) Minority carriers are aided by the **junction potential**.


Reverse bias of a pn junction




- ▶ The reverse voltage causes the depletion region to **widen** .
- ▶ The **electrons** in the **n**-type material are attracted toward the **positive** terminal of the voltage source .
- ▶ The **holes** in the **p**-type material are attracted toward the **negative** terminal of the voltage source .



Forward bias of a pn junction




- ▶ The forward voltage causes the depletion region to **narrow**
- ▶ The **electrons** and **holes** are pushed toward the **p-n** junction
- ▶ The **electrons** and **holes** have sufficient energy to cross the **p-n** junction




Barrier Potential

- *The barrier potential of a pn junction depends on several factors, including the type of semiconductor material, amount of doping, and the temperature*
- *Typical at 25 deg C it is ~ 0.7 for silicon and ~ 0.3 for germanium*

Semiconductor Diode



(a) Circuit symbol



(b) Volt-ampere characteristic