


Dr. Khalil Qatu


ENCE 331: Compressibility of soil

Previously in Soil Mechanics



Why shear strength ??

- Soil is made from individual particles (sediments)
- The strength of the soil is contributed to the interaction between these particles
- This interaction takes two forms
 - Cohesion (adhesion between the particles)
Depends on type of soil (Clay soils)
 - Friction
Depends on roughness of particles, particle size, and normal stress (Granular soils)
- The forces that break this interaction are shear forces



Mohr-Coulomb Failure criteria

- The components of shear stress are:
 - Cohesion
 - Friction
- Mohr (1900) presented a theory for rupture in materials that contended that a material fails because of a critical combination of normal stress and shearing stress

$$\tau_f = c' + \sigma' \tan \phi' \quad \text{OR} \quad \tau_f = c + \sigma \tan \phi$$

where c = cohesion


ϕ = angle of internal friction

σ = normal stress on the failure plane

τ_f = shear strength

Table 12.1 Typical Values of Drained Angle of Friction for Sands and Silts

Soil type	ϕ' (deg)
<i>Sand: Rounded grains</i>	
Loose	27–30
Medium	30–35
Dense	35–38
<i>Sand: Angular grains</i>	
Loose	30–35
Medium	35–40
Dense	40–45
<i>Gravel with some sand</i>	34–48
<i>Silts</i>	26–35





Mohr's Circle and stress transformation

- Since we usually deal with vertical stress (Comp), we need to find the most critical surface (failure plane)
- For this we use,??

$$\theta = 45 + \frac{\phi'}{2}$$

$$\sigma'_1 = \sigma'_3 \tan^2\left(45 + \frac{\phi'}{2}\right) + 2c' \tan\left(45 + \frac{\phi'}{2}\right)$$




LAB tests to determine shear strength of soil

- There are many test that can be conducted either in the lab or in the field to determine the soil strength parameters (C, ϕ)
 - LAB tests
 - Direct Shear Test.
 - Triaxial Compression Test.
 - Unconfined Compression (UCC) Test.
 - Field tests
 - Vane Shear Test.
 - Bore Hole Shear Test.
- Lab tests are more accurate, but require more time and samples will be disturbed to some degree
- Field tests are usually faster, no need to take samples (Undisturbed soil), but it is less accurate.



Direct shear test

- The test apparatus is shown
- First the Normal force is applied incrementally so that the sample can consolidate
- The normal stress is
$$\sigma = \text{Normal stress} = \frac{\text{Normal force}}{\text{Cross-sectional area of the specimen}}$$
- Then a Horizontal force is applied to the Top half and increased incrementally to failure, and the lateral displacement is measured

- The shear
$$\tau = \text{Shear stress} = \frac{\text{Resisting shear force}}{\text{Cross-sectional area of the specimen}}$$





Direct shear test



Direct shear test

- The test is repeated for different specimens of the same soil for different Normal stresses
- Each time the Normal stress and the shear stress at failure are recorded



Direct shear test

- General Comments


- The soil is not allowed to fail along the weakest plane but is forced to fail along the plane of split of the shear box
- The shear stress distribution over the shear surface of the specimen is not uniform
- Progressive failure

- Despite its shortcomings The direct shear test is simple to perform
- The test can be utilized to determine the interface properties

$$\tau_f = c'_a + \sigma' \tan \delta'$$


where c'_a = adhesion

δ' = effective angle of friction between the soil and the foundation material





Tri-Axial test

- The triaxial shear test is one of the most reliable methods available for determining shear strength parameters
- Soil specimen about 36 mm (1.4 in.) in diameter and 76 mm (3 in.) long
- The specimen is subjected to a confining pressure by compression of the fluid in the chamber
- The axial load applied by the loading ram and the corresponding axial deformation is measured by a ring or load cell attached to the ram





Tri-Axial test

- The test is performed in two stages
 - Applying the confining pressure (σ_3)
 - If the drainage is open, then the excess pore water pressure is
 - Depending on the drainage, the test can be Consolidated or Unconsolidated test
 - Applying the deviatoric pressure ($\Delta\sigma_d$)
 - If the drainage is open, then the excess pore water pressure is
 - Depending on the drainage, the test can be Drained or Undrained test
- Depending on the drainage conditions at each stage the following three standard types of triaxial tests generally are conducted:
 - Consolidated-drained test or drained test (CD test)
 - Consolidated-undrained test (CU test)
 - Unconsolidated-undrained test or undrained test (UU test)




Tri-Axial test

- Consolidated-drained test or drained test (CD test)
 - the saturated specimen first is subjected to an all-around confining pressure, σ_3 , by compression of the chamber fluid
 - The sample is allowed to consolidate until the pore pressure is completely dissipated
 - Then the deviatoric axial stress is applied incrementally to failure
 - The stress state for any element shown is called
 - Total and effective confining stress = $\sigma_3 = \sigma'_3$
 - Total and effective axial stress at failure $\sigma_1 = \sigma'_1 = \Delta\sigma_d + \sigma_3$
- The test is repeated at least two times at different confining pressures
- The confining pressure and the deviatoric stress at failure are recorded





Tri-Axial test


- Consolidated-drained test or drained test (CD test)



Loose Sand
or
NC Clay



Dense Sand
or
OC Clay



Tri-Axial test

- Consolidated-drained test or drained test (CD test)

Example:

The results of two drained triaxial tests on a saturated clay follow:

Specimen I:

$$\sigma_3 = 70 \text{ kN/m}^2$$

$$\Delta\sigma_{d,f} = 130 \text{ kN/m}^2$$

Specimen II:

$$\sigma_3 = 160 \text{ kN/m}^2$$



$$\Delta\sigma_{d,f} = 223.5 \text{ kN/m}^2$$

Determine the shear strength parameters.

Tri-Axial test



- Consolidated-Undrained test (CU test)

- This test is the most common type of triaxial test
- We can measure the effective soil strength parameters (C' , ϕ') and the total stress parameters (C , ϕ)
- Consolidated-drained tests on clay soils take considerable time.
- Saturated soil specimen is first consolidated by an all-around chamber fluid pressure σ_3
- Then the drainage is closed and the deviatoric axial stress is applied to failure $\Delta\sigma_{d,f}$
- This will result in an increase in the pore water pressure $\Delta u_{d,f}$
- Major principal stress at failure (total): $\sigma_1 = \sigma_3 + \Delta\sigma_{d,f}$
- Major principal stress at failure (effective): $\sigma'_1 = \sigma_1 - \Delta u_{d,f}$
- Minor principal stress at failure (total): σ_3
- Minor principal stress at failure (effective): $\sigma'_3 = \sigma_3 - \Delta u_{d,f}$



Tri-Axial test

$$\phi = \sin^{-1}\left(\frac{\sigma_1 - \sigma_3}{\sigma_1 + \sigma_3}\right) \quad \phi' = \sin^{-1}\left[\frac{\sigma_1 - \sigma_3}{\sigma_1 + \sigma_3 - 2(\Delta u_d)_f}\right]$$



Tri-Axial test

- Consolidated-Undrained test or drained test (CU test)

- Example:

A specimen of saturated sand was consolidated under an all-around pressure of 105 kN/m². The axial stress was then increased, and drainage was prevented.



The specimen failed when the axial deviator stress reached 70 kN/m². The pore water pressure at failure was 50 kN/m². Determine

- a. Consolidated-undrained angle of shearing resistance, ϕ
- b. Drained friction angle, ϕ'

Tri-Axial test




- Unconsolidated-Undrained Triaxial Test (UU)

- This test usually is conducted on clay specimens
- We can measure the effective soil strength parameters (C', ϕ') and the total stress parameters (C, ϕ)
- Because drainage is not allowed at any stage, the test can be performed quickly
- Saturated soil specimen is subjected to an all-around chamber fluid pressure σ_3 with drainage closed
- The pore water pressure in the soil specimen will increase by u_c
- Then the deviatoric axial stress is applied to failure $\Delta\sigma_{d,f}$
- This will result in an increase in the pore water pressure $\Delta u_{d,f}$
- The total pore water pressure u in the specimen at any stage of deviator stress application $u = u_c + \Delta u_d$
- The added axial stress at failure $\Delta\sigma_{d,f}$ is practically the same regardless of the chamber confining pressure



Tri-Axial test

- Unconsolidated-Undrained Triaxial Test (UU)



Tri-Axial test

- Unconfined Compression Test on Saturated Clay
 - This test is a special type of unconsolidated-undrained test that is commonly used for clay specimens
 - Since the undrained shear strength of clay doesn't depend on the confining pressure σ_3
 - The test is performed without any confining pressure $\sigma_3 = 0$
 - Theoretically, for similar saturated clay specimens, the unconfined compression tests and the unconsolidated-undrained triaxial tests should yield the same values of c_u
 - In practice, however, unconfined compression tests on saturated clays yield slightly lower values

